

how to fold your



1. Begin by holding the decoy with the head lying on the ground as shown. Then, step on the body wire in the neck area and grasp each side of the decoy about 1/3 down the body with your thumbs pointing down.
2. Then, start bending the rear end of the body over backwards (when doing this roll the bands inward).
3. Continue folding the rear end backward and at the same time bring your hands together.
4. Cross your hands past each other at the same time and the rear end will tuck under.
5. Push everything to the ground.
6. Congratulations you've folded the decoy.

Enclosed are two different support poles that are labeled "front leg" and "backleg". Insert the rear leg pole into a sleeve at the bottom of the rear leg and hook the elastic strap into the adjustable hook on the leg pole. Do the same with the front leg pole into the front leg.

We would love to have your success stories and pictures, or even videos. You can send them to:

Montana Decoy, Inc.

Jerry McPherson

P.O. Box 2377

Colstrip, Montana 59323

email: jmcperson@tgrsolution.net

Check out our web site at www.montanadecoy.com

Phone: 406-748-3092

MADE IN THE USA



CAUTION

The Montana Decoy looks so real that all precautions must be taken during archery season. Animals tend to be aggressive during the rut. Also, another hunter might mistake the decoy for the REAL THING! DO NOT USE the MONTANA DECOY during rifle season.